

Installation Guide Voltex LED Oyster Ceiling Light



Voltex Electrical

Australia www.voltexelectrical.com.au P: 1300 722 275 E: sales@voltexelectrical.com.au

New Zealand www.voltexelectrical.co.nz P: 0800 55 66 33 E: sales@voltexelectrical.co.nz





Safety Instructions

Basic safety precautions should always be followed when installing, including the following:

- 1. Read all instructions.
- 2. For Indoor use only. Do not install luminaires in damp or wet locations.
- 3. Do not install any luminaire near a heat source.
- 4. Turn off power before installation or before doing any maintenance work.
- 5. Do not exceed the nominal supply voltage or amperage ratings.
- 6. Dimmable version could be compatible with a wide range of recommended TRIAC dimmers.
- 7. Non-dimmable version not for use with dimmers.

Installation Procedure

WARNING!

1.Switch off before installation.

2.Switch on only after complete installation and examination of the circuit. 3.Professional electrician for installation and maintenance only.



Turn Off power supply before starting any installation. Read instructions & check you have all the tools & accessories to complete the installation correctly.

How to install

Step 1

Take out ceiling light and accessory pack from box.

Step 2

Using screwdriver turn the bracket in anticlockwise direction and take it out.



Step 3

Determine mounting location and fix bracket with screws into the ceiling.



Step 4

For color changeable model (controlled by Slide Switch in lamp), please select light color before mounting to ceiling or wall, see below picture.





2. Choose color by slide switch with corresponding

color temperature.



3. Insert rubber stopper back into slide switch properly.

Step 5

Switch off, wiring "live", "Neutral" to teminal block respectively.



L = BROWN

Step 6 Aim the buckle at the th

Aim the buckle at the the gap of installation bracket and push it upward, adjust the lamp's position clockwise and counter-clockwise to fit the lamp into the bracket, then rotate the lamp clockwise until it is fixed well.

Step 7

Connect the lamp to the main supply after finishing the installation.



Aim the buckle at the gap of installation bracket





The LED in this luminaire is not replaceable; when the LED reaches its end of life the whole luminaire shall be replaced.