



Outdoor Sensor Light OMSL2B and OMSL2W

Operation as a manually switched on/off light only (No sensor functions)

The OMSL2B and OMSL2W can be installed and wired as a manually operated light, bypassing the sensor functions.

To wire the product to operate in this way, a switched Active needs to be looped between the Active supply terminal (A) and the Sensor override terminal, as shown in the diagram below.

