


Fan Switch Instruction

Cat No: CSMR4



This four position switch is suitable for use with ceiling fans up to 100W.



Installation:

This product must be installed by a suitably qualified person.

1. Before starting work on the device ensure the circuit has been isolated.
2. Disconnect and remove the existing fan switch noting the configuration of the capacitor tails.
3. Insert the Voltex CSMR4 in the plate and reconnect the wiring as shown if the capacitor configuration is as shown in the diagram.
 - a. Active to the centre terminal [L]
 - b. Switch wire and capacitor pack output together in terminal 1
 - c. Higher capacitance input to terminal 2
 - d. Lower capacitance input to terminal 3
4. Replace the knob and fix plate back to the wall.
5. Reconnect the circuit and test.

Note: The connection diagram shown is typical for many brands of fans. However other capacitor configurations are quite possible. If unsure, check the product's installation booklet or the fan supplier.

Warranty:

The CSMR4 is covered by Voltex's 'Lifetime' - 25year warranty.