ITEMS INCLUDED











INSTRUCTIONS

1.



Punch out with a screwdriver

3.







Using a knife, notch out a small section in the front cover to accomodate the lock.

