



# VOLTEX<sup>®</sup>

## Installation Guide Suspension Switched Socket



### Recommended Flexible Cable Stripping Diagram




To access Earth Terminal screw, unclip socket mechanism.  
Recommended for up to 1.5mm<sup>2</sup> heavy duty three core flexible cable.

## WIRING INSTRUCTIONS:

NOTE: Earth wire is connected directly to the socket and Active/Neutral are connected to the switch.

1. Strip cable insulation as shown in the Stripping diagram on Page 1.
2. Pass cable through the hook & thread.
3. Pass cable through the rubber bushing.
4. Pass cable through the back cover.
5. Connect the EARTH wire [Green/Yellow or Green] to the socket terminal marked 'E'.
6. Connect the Active wire [Brown or Red] to the switch terminal marked 'A'.
7. Connect the Neutral wire [Blue or Black] to the switch terminal marked 'N'.
8. Ensure the Earth wire is placed into the socket wire retaining path as shown.
9. Check the wires are in the correct position, as shown, and terminal screws are tight.
10. Slide cover into position, ensure outer sheath of cable overlaps the internal cover rib.
11. Clip cover to socket assembly and tighten the two cover fixing screws.
12. Slide the rubber bushing and hook & thread down cable and screw the hook fully into position.
13. Suspend socket using suitable hanging chain or cord, and ensure cable tension is taken up by the hook.



AU

Phone: 08 8374 4200  
Email: [sales@voltexelectrical.com.au](mailto:sales@voltexelectrical.com.au)  
[www.voltexelectrical.com.au](http://www.voltexelectrical.com.au)

NZ

Phone: 0800 55 66 33  
Email: [sales@voltexelectrical.co.nz](mailto:sales@voltexelectrical.co.nz)  
[www.voltexelectrical.co.nz](http://www.voltexelectrical.co.nz)

**VOLTEX**<sup>®</sup>